



All manufacturer's names,numbers,photos,product description and/or part numbers are used for reference purposes only & it is not implied that any part listed is the product of these manufacturers. Since Approvement are made from time to time, the illustration and specifications are subject to change without notice.



8. SUCTION VALVE & COVER ASSEMBLY (for 220Cyl.)

No.	Description	Ref Part No.	QTY
ı	Suction Valve Assembly (Second Stage)	1903256990	-
2	O-Ring	H0221150	1
3	O-Ring for piston Dia. 51	H0210150	1
4	Piston for Regulation	B0903164	1
-	Suction Valve Cover Assly.	Z2706163	1
5	- Suction Valve cover	C0220164	1
6	- Sleeve Dia. 51	C6567164	1
7	Piston Dia. 51	B0902164	1
10	Copper Washer	M3637150	1
14	Split Pin Dia. 2.5	M5108150	1
ı	Suction Lifter Assembly - FAU (First & Second Stage)	C9007164A	1
1	- Guide nut for Lifter	M2081163	1
8	- Circlip Dia. 40	M4009164	1
9	- Washer	M3638162	1
11	- Lock for Screw	M3840162	1
12	- Castle Nut	M2221160	1
13	- Spring	H3483164	1
15	- Lifter	C9007164	1
	Valve Service Kit (Second Stage)	1903005795	-
	- Valve Plate	E2229164	1
	- O Ring for Unloader Piston	H0210150	1
	- O Ring for Valve Holder	H0221150	1
	- Lift Washer Top	H0808164	1
	- Lift washer Bottom	H0809164	1
	- Valve Spring	H3488164	8
	- Cu. Washer	M3637150	1
	- Split Pin	M5109150	1

Note :- Suction Valve Assembly - Second Stage - Qty. : 06nos.